


# Bed Frame


San Francisco - Twin

SIMPLIFIED  
BUILDING




61-6  
Flange

5x




10-6  
Single Socket Tee

14x




15-6  
Angled Flange

2x




20-6  
Side Outlet Elbow

3x




21-6  
Side Outlet Tee

5x



- 1/4" Hex



4x

24 Inches

6x

39 Inches

2x

49 Inches



5x

72 Inches



4x

75 Inches


**1.**




**2.**



**3.**



**4.**



## INSTALLATION TIPS

1. Adjust individual fittings to square and level the frame.
2. Use a socket wrench with a 1/4" hex bit for faster assembly.
3. If the frame seems wobbly, there may be a pipe slightly out of place. Loosen a few setscrews in the problem area and adjust as necessary.
4. Finish up your assembly by ensuring all setscrews are tightened properly.
5. Use a sheet of plywood or slat platform underneath the mattress.

